



Solarflex SA.

User Manual.

Typical Digital Connectors – A Guide.

The following are typical Connectors for Digital Devices.

Cameras and Cellphones.

Micro USB



Mini USB



Samsung Instinct



Nokia N73

1650, 2630, 2760, 3109 Classic, 3110 Classic, 3250, 3500, 5070, 5200, 5300 XpressMusic, 5310, 5500 Sport, 5610, 5700 Xpress Music, 6070, 6080, 6085, 6086, 6101, 6103, 6110 Navigator, 6111, 6120, 6121, 6125, 6131, 6136, 6151, 6233, 6234, 6267, 6270, 6280, 6300, 6301, 6500, 6555, 6600 Fold, 7360, 7370, 7390, 7500, E50, E51, E61, E61i, E65, E90, N70, N71, N72, N73, N76, N77, N78, N80, N81, N90, N91, N92, N93, N93i, N95, N800, N810



Universal

S - 2.3x0.7mm



Universal

H - 3.5x1.1mm



Universal

H - 3.5x1.3mm



Universal

I - 4.0x1.7mm



Universal

E - 5.5x2.1mm



Optional Phone Adapters

iPhone

Charges the iPhone 3GS, 3G and 2G and iPod touch, shuffle and classic, Note: You can also charge current model iPhones direct from the battery using the USB cable supplied by Apple.



Japanese Phone Set



Car Charger Socket

Set the panels or battery to 12V to use with your car charger. Fits 3.5 x 1.3mm plugs



Alcatel 511

0T511, 0T512, etc.



Alcatel 735

735



Compaq iPaq

H1700, H1900, H1910, H1915, H1920, H1930, H1935, H1937, H1940, H1945, H2200, H2210, H2215, H3000, H3600, H3800, H3830, H3835, H3850, H3870, H3875, H3900, H3950, H3955, H3970, H3975, H4100, H4150, H4155, H4300, H4350, H4355, H5100, H5150, H5400, H5450, H5455, H5500, H5550, H5555, H6300, H6310, H6320, H6325, H6340, H6365, HW6500, HW6510, HW6515, HX2000, HX2110, HX2410, HX2415, HX2750, HX2755, HX4700, HX4705, RX3100, RX3115, RX3400, RX3417, RX3700, RX3715, RZ1700, RZ1710, RZ1715



Motorola V Series

120E, 120X, A835, A920, A1000, C331, C333, C343, C353, C975, E398, E550, MPx220, ROKR E1, T280, T280i, T300p, T720, T720i, T721, T729, T730, T731, Timeport 270C, Timeport 280, V60, V60c, V60g, V60i, V60p, V60t, V60x, V66, V66i, V70, V80, V120, V200, V300, V400, V500, V505, V525, V547, V550, V551, V600, V620



Nokia 1100

1100, 1221, 1260, 1261, 2115i, 2116i, 2125i, 2126i, 2128i, 2260, 2270, 2285, 22300, 600, 3100, 3120, 3200, 3205, 3220, 3285, 3300, 3360, 3361, 3390, 3395, 3520, 3560, 3570, 3585, 3585i, 3586i, 3587i, 3588i, 3589i, 3590, 3595, 3620, 3650, 3660, 5100, 5140, 6010, 6015i, 6016i, 6019i, 6020, 6030, 6061, 6062, 6100, 6170, 6200, 6225, 6230, 6235i, 6236i, 6250 6i, 6255i, 6256i, 6310i, 6265i, 6340, 6340i, 6360, 6370, 6385, 6560, 6585, 6590, 6590i, 6600, 6610, 6620, 6630, 6630b, 6651, 6670, 6682, 6800, 6820, 6822, 7210, 7250i, 7270, 7280, 7380, 7610, 7710, 8260, 8265, 8265i, 8270, 8290, 8390, 8801, 9290, 9300, 9500, E60, E70, etc.



Nokia Car Charger

All phones as N73. In Europe charge circuitry on some Nokia phones prevent charging from the N73 adaptor tip. In this case, use this car charger instead.



Palm Tungsten



Palm V



Samsung A310

A310, A530, A570, A630, A650, A670, A790, A850, A890, A950, A970, N330, S300, SCHA310, SGHX105, etc.



Samsung Instinct

L600, SGH-L760, SGH-M110, SGH-T229, SGH-T339, SGH-T409, SGH-T429, SGH-T439, SGH-T539 Beat, SGH-T729 Blast, SGH-T739 Katalyst, SGH-T819, SGH-U900, SPH-1325 Mysto Helio, SPH-A513, SPH-A523 Fin, SPH-I325 Mysto ACE, SPH-M300, SPH-M305, SPH-M310, SPH-M510 Slash, SPH-M520, SPH-M800 Instinct, SPH-Z400



Samsung T509

SCHR510, SCHU420, SCHU740, SGHA707, SGHD800, SGHD807, SGHD820, SGHD900, SGHi607 Blackjack, SGHP300, SGHT509, SGHT509s, SGHT519, SGHT629, SGHT809, SGHZ510, SGHZ540, SPHA303, SPHA503 Drift, SPHM610, T509



Siemens A52

A52, A55, A57, A60, A62, A65, A70, A72, A75, AL21, AX72, AX75, C55, C60, C62, C65, C72, C75, CF110, CF62T, CF75, CFX65, CL75, CX65, CX70, CX75, M46, M50, M55, M65, M65 Rescue Edition, M75, MC60, ME75, S55, S65, S75, SF65, SK65, SL65, SL75, SP65, SX1, SXG75...



Siemens S46

M50, S46



Sony Ericsson J100

W830c, W850i, W900c, W900i, W950i, W958c, Z520a, Z520c, Z520i, Z525a, Z525i, Z530c, Z530i, Z550a, Z550c, Z550i, Z558c, Z558i, Z610i, Z710c, Z710i



Sony Ericsson T28

Z300, Z300a, Z300c, Z300i, Z310i, Z320i, Z500a, Z502a, Z520i, Z530i, Z550i, Z600, Z608, Z610i, Z710i, Z750i, Z770i, Z780i, Z800i



Sony N710

Clie S/N: N710C/G, N750C/G



Sony T665

Clie T/NR: T665C/H, TG50/H



Treo 650

Treo 600, Treo 650, Treo 680, Treo 700p, Treo 700w, Treo 700wx, Treo 750, Treo 750p, Palm Centro, Palm 90, Palm 180, Palm 180g, Palm 270, Palm 300, Lifedrive, Tungsten E2, Tungsten T5, Tungsten TX, TX



Camera Chargers

Canon BP511



Canon NB2L



Nikon EN-EL3



www.solarflex.co.za

Mail: info@solarflex.co.za